



**Errata**

**Manual of Cross-Connection Control – 10th Edition**

**Chapter 10 – Standards**

**Issued 1 January 2012**

The Foundation has published a second printing of the Manual 10th Edition, dated 2012.

The second printing includes corrections in the Standards contained in Chapter 10.

<b>Page No.</b>	<b>Chapter 10 - Standards (<del>Deletion</del> / <u>Addition</u>)</b>			
329	Page numbers corrected			
331	Table 10-1			
	Size of the Assembly (1)		Rated Flow (2)	
	(inches)	(mm)	(gpm)	(L/s)
	1/2	(15)	7.5*	<del>(0.39)</del> (0.47)
346	Blank item “d” deleted			
356	10.1.2.2.3.9 step c: With the backpressure established as in step <del>e</del> <u>b</u> above...			
364	10.1.2.3.3.6 step b, last sentence: If necessary, remove or disconnect the loading on the first <u>second</u> check valve...			
388	10.1.2.7.3.5, Requirement, Following statement applies to all line sizes: ... for a period of one minute without any structural damage which allows leakage.			