

inside: is my field test kit leaking? / identify a backflow preventer... and more

Cross



Summer 2006

Direct vs **Indirect** Cross-Connections

The understanding of what constitutes a direct vs. indirect cross-connection is often misunderstood. Many assume a connection that is hard-plumbed or permanently affixed is a direct connection, while an indirect connection would use a hose or maybe a removable connection.

The actual definition of an indirect cross-connection, as stated in the Manual of Cross-Connection Control, Ninth Edition, is a connection that is subject to backsiphonage only. The Manual defines a direct cross-connection as a connection that is subject to both backpressure and backsiphonage. Whether there is a temporary hose or permanent pipe making the connection is irrelevant. It is true that many indirect cross-connections may be made with a hose. Often hoses are used to fill vessels, or to add makeup water to



A fixed pipe with an Indirect Cross-Connection

Contents

- Is my field test kit leaking? p. 3
- • Properly identify a backflow preventer p. 4

PVB- rotating that **No. 2 test cock** by **rotating** the **No.2 shutoff valve** p. 7

ponds, pools, even cooling towers. They may also, however, be used to make connections between a water line and other substances which may be under pressure. A hose connected to a hose bib on a boiler for make-up water, for example, could be subject to both

continued on page 5



Foundation Membership

The Foundation's Membership Program provides many benefits to the Members of the Foundation. These include: a twenty-five percent discount on manuals, twenty percent discount on Foundation Training Courses for any employee of the Member company/organization, the *List of Approved Backflow Prevention Assemblies*, printed quarterly, and access to the up-to-the-minute version of the *List* for those Members with Internet access.

Members are encouraged to call the Foundation with technical questions. The Foundation's Engineering Staff is available to assist members with the various aspects of field testing backflow preventers, installing backflow preventers and administering their cross-connection control program.

Many consider their Membership with the Foundation one of their best forms of insurance to protect the agency from liability involved when a distribution system becomes contaminated or polluted through cross-connections. Membership in the Foundation helps to provide the tools needed to effectively initiate and run a cross-connection control program.

Below is a list of those who have become Members of the Foundation this past quarter:

Alaska Rural Water Assoc.	Los Padres National Forest
Azmo Mechanical Inc.	City of Menlo Park
Bass Fire Protection	Patrick Freiha
BCA	Payson Water Department
C2 Services	City of San Diego
Clark Nexsen	City of San Jose
CRD Water Services	Spanish Fort Water System
David Burgueno	Swartz Plumbing
Education Services	University of California, Davis
Flow & Safety Services	Walker Lake Water District GID
HDR Engineering, Inc.	Watersmith LLC
Kennebec Water District	Winstel Controls, Inc.
Lake Don Pedro CSD	


Cross Talk is published by the Foundation for Cross-Connection Control and Hydraulic Research at the University of Southern California for Foundation Members. Limited additional copies are available to Members upon request. 2006 © University of Southern California. All rights reserved.

Is my field test kit leaking?

While field testing a DC, PVB, or SVB, how many times have you pressurized the high side of your field test kit and wondered why you get a squirt of water out of the low side of the field test kit? Since the field test for these assemblies only requires the use of the high side hose, the unused low side hose may be detached or left coiled around the field test kit. The normal reaction is "oops, I left my needle valves open on my gage." But then after checking the needle valves, and finding them closed properly, you are left wondering where the water came from.

If we look at the basic cross-section of the field test kit, we may see what occurred. The field test kit is designed to indicate the difference in pressure (i.e., differential pressure) between the high side and low side pressure sources. When the pressure is the same on both sides of the field test kit, the differential pressure is 0.0 PSID (pounds per square inch differential), and indicated as such.


As pressure is admitted into the high side



test kit. However, if the field test kit was not fully drained of water, there may be some residual water remaining in the field test kit. Should there be water remaining in the gage when the pressure is admitted into the high side of the field test kit, the residual water in the field test kit may be displaced or pushed out of the low side.

Once the field test kit has been fully pressurized on the high side, the water should stop coming out of the low side. If the water continues to drip/flow out of the low side,

of the field test kit (with atmospheric pressure on the low side). the field test kit reading will begin to rise. The pressure measuring element inside the field test kit will begin to move/deflect in response to the



the needle valves need to be inspected to ensure that they are not the cause of the leak. If water still continues to drip/flow out of the low side after inspecting the needles valves.

changing pressure. (Note: Digital type field test kits may not have a common pressure measuring element, but rather two separate pressure measuring elements. The description below may not be applicable.)

After a field test is completed, the tester typically drains all of the water out of the field

then the field test kit may require additional repairs.

The resulting "squirt" of water may catch some off guard, but if you understand the inner workings of the field test kit, it can be easily explained. ■

Properly identify a backflow preventer

The Foundation office, on a regular basis, receives phone calls from concerned members regarding markings (i.e., make, model number, size) that are sometimes hard to find on all types of backflow prevention assemblies. Questions range from, where the location of the model number is on the assembly to matching that model number with that on the Foundation's List of Approved Backflow Prevention Assemblies.

In the Manual of Cross-Connection Control, Ninth Edition Section 10 the Foundation puts forth a Standard for the backflow prevention assemblies. The Foundation states in section 10.1.1.4 that:

Size, model and serial number markings on backflow prevention assemblies for sizes 5/8 x 3/4-inch through 16-inch shall be with letters or numbers at least 1/4 inch (6mm) in height. For backflow prevention assemblies sized 1/4, 3/8, and 1/2-inch, the size, model and serial number markings shall be with letters or numbers at least 1/8 inch (3mm) in height. All lettering cast on a body shall be a minimum of 1/4-inch in height. All marking shall be easily read and shall be either cast or stamped on the body; or stamped, engraved, or etched on a durable nameplate permanently affixed to the body of the assembly. should be placed, therefore the markings vary from assembly to assembly. Keep in mind when trying to locate the information it will always be found on the body of the assembly and not on the shutoff valves or test cocks. Keep in mind that all the information may not be found in one place.



Wilkins RP 10"

For example, the make and model of the assembly may be located on the top of the body whereas the rest of the information may be located on both sides of the assembly. In addition many of the assemblies have been in the field for years and factors including vandalism or weather conditions may have

continued on page 6

The problem a number of members come across is locating the specific information on the body. The Standard put forth by the Foundation does mention that the markings shall be located either on both sides of the body or on a top surface of the body. It does not specifically mention where on both sides of the body or on top of the body the markings



Watts 909RPDA 6"

Direct vs Indirect Cross-Connections

continued from page 1

backsiphonage and backpressure and would, therefore, be considered a direct cross-connection.

If, however, there is a permanently plumbed water line that drops into an open mixing tank, it would not be a direct cross-connection. This would be permanently plumbed, yet it would not be a direct crossconnection because it would not be subject to backpressure.

Another common misconception is that an actual cross-connection is a direct cross-connection and a potential crossconnection is an indirect cross-connection. This is not true as shown in the

example with the hose. Two hose bib connections may be near one another, with one supplied from a potable water source and the other connected to a pressurized tank with

non-potable water. Even though there may be no connection at the time the hose bibs are inspected, if the hose connection is made between the two hose bibs, the cross-connection will be subject to backpressure.

If we look to the definition of a cross-connection in the Manual of Cross-Connection Control, we find that a cross-connection is, by

definition, "...any actual or potential connection or structural arrangement between a public or a consumer's potable water system and any other source or system, through which it is possible to introduce into any part of the potable system any used water, industrial fluid, gas or substance other than the

intended potable water with which the system is supplied." Therefore, a potential connection is considered a cross-connection and should be protected.

One may also come across a pipe used as a fill-line to a mixing tank. The pipe may be permanently plumbed and even welded to the side of the tank. However, if this is an open tank, the connection would only be subject to backsiphonage and not backpressure, even though it is a permanent connection firmly plumbed to the tank.

It is important that all those involved in cross-connection control, not only understand the correct terminology, but also provide the proper level of backflow protection to the specific cross-connection at hand.

Direct Cross-Connection



Direct Cross-Connection

Think **twice** before **rotating** that **No.2 test** of Pressure Vacuum Breaker

Field-testing a backflow prevention assembly can sometimes be a very troublesome task to complete. As a tester, you hear horror stories from time to time about the struggles a Tester has to go through to conduct a field test on



Watts PVB- Correct

a backflow prevention assembly. Have you ever walked up to an assembly and found it buried under several feet of rubble? Or, have you encountered a test cock or shutoff valve that is just too difficult to reach? Maybe rotating the valve one bolthole here or turning a valve there doesn't seem like a big deal in order to get the job done. And, even though some of the time it might seem tedious to conduct a field test on a backflow prevention assembly it is crucial that the field test is done in the correct manner to get accurate results. Such is the case with performing a field test on a Pressure Vacuum Breaker. Testing a Pressure Vacuum Breaker (PVB) may not be as complicated as its counterparts, the Double Check Valve Assembly or the Reduced Pressure Principle Backflow Prevention Assembly, but completing each step correctly is as crucial. The PVB consists of (2) shutoff valves, (2) test cocks, a check valve and an air inlet valve. A common mistake performed during the field test procedure occurs when the tester is performing the air inlet valve opening point portion of the test. In some cases the No. 2 test cock is attached to the No. 2 shutoff valve portion of the assembly (See figure on the left).

In the Foundation's Manual of Cross-Connection Control, Ninth Edition, Section 9.4.2. step (g) the tester is instructed to slowly open the high side bleed valve no more than a onequarter (1/4) turn, being careful not to drop the differential pressure reading on the gage too fast. Record the differential pressure reading on the gage when the air inlet valve opens then open the high side bleed valve to drain water from the body. Observe that the air inlet valve has opened to its fully open position. But, what if the air inlet valve does

Properly identify a backflow preventer

continued from page 6

caused the markings to be difficult to read or, in some cases, the markings have totally disappeared.

It is vital, that in all cases, any and all information that can be obtained from the assembly be noted. And, if any information is missing, tools like the Internet can be used to obtain the missing details. Visiting a manufacturer's website can be helpful in differentiating between similar assemblies and if that still doesn't solve the mystery of the assembly give the manufacturer a call.

It is critical that the model of the backflow prevention assembly is accurate since the model, number or name, is the key marking in locating it on the Foundation's List of

ock by rotating the No.2 shutoff valve

not open to its fully open position, then what might be the problem? The solution might have to do with a modification the installer made without much thought.

The PVB illustrated in the ninth edition of the Manual has the No. 2 test cock on the body of the PVB where it is easily accessible and convenient. But, in some cases the No. 2 test cock is located on the No. 2 shutoff valve portion of the assembly and is pointing downward. When the tester attaches the high side hose of the differential pressure gage to test cock No. 2 it may become cumbersome to reach underneath the assembly and gain access to the No. 2 test cock. The No. 2 shutoff valve may be rotated upward for easier access to the No. 2 test cock without giving it a second thought (See figure on the right).

However, rotating the No. 2 shutoff valve, allowing the tester more freedom when attaching the high side hose, may not allow the air inlet valve to open fully. Rotating the No. 2 shutoff valve so that the No. 2. test cock is pointed upward prevents any water from being drained from the body of the PVB. The tester may open the high side bleed needle valve completely and yet the air inlet will not open to its fully open position.

Therefore, it is crucial that the No. 2 test cock be left in the original position and the high side bleed valve of the differential pressure gage is opened to allow any water to drain out of the body of the assembly thus allowing the air inlet to open fully.



Watts PVB- Incorrect

Simple modifications, like the one mentioned above, are what can cause an assembly to pass or fail in the field. And, sometimes trying to make the backflow prevention assembly more hassle-free isn't always the best way to go. ■

Approved Backflow Prevention Assemblies. Members must remember that the model marking on the assembly must match exactly to what is listed on the List in order for the assembly to be an approved assembly. Therefore, it is essential to identify the backflow prevention assembly properly; whatever minute detail may be overlooked or assumed can cost an agency or business thousands of dollars to replace an unapproved assembly. The model marking must match exactly, character for character, digit for digit, on both the List of Approved Assemblies and on the body of the backflow prevention assembly in order for it to be an approved USC assembly.

USC

Training Courses

Tester Course

Los Angeles, CA 9-13 October 2006

Los Angeles, CA 8-12 January 2007

Specialist Course

Santa Clara, CA 13-17 November 2006 Los Angeles, CA 22-26 January 2007

Upcoming Events

Inland County Backflow Group Seminar San Bernardino, CA 21 September 2006

ABPA Western Regional Backflow Conference •Las Vegas, NV 9-10 October 2006


Western Washington Annual Seminar •Tacoma, WA 18 October 2006

Contact Information • • •

Phone: 866-545-6340 Fax: 213-740-8399 E-mail: fccchr@usc.edu

Website: www.usc.edu/fccchr

First Class US Postage PAID University of Southern California



Foundation for Cross-Connection Control and Hydraulic Research

University of Southern California Kaprielian Hall 200 Los Angeles, California 90089-2531

